Appendix to Certificate EC-87/02/57/b

MODEL NUMBER GUIDE - FIREYE (with description of timing/functional options:)

This model is re-branded version and is identical to the Eclipse model

Product Model Number Guide	Make one selection each from Tables I through VIII								
	Model	I	II	III	IV	V	VI	VII	VIII
	SB	_ _	_	_	_ _ _	_ _	_ _	_ _	_ _ _

TABLE	DESCRIPTION	SELECTION
TABLE I POWER SUPPLY	102-132VAC, 50/60Hz 204-264VAC, 50/60Hz	12 23
TABLE II SEQUENCE	No-Purge* Purge Modulation**	N P M
TABLE III FLAME FAIL RESPONSE	3 second FFRT 1 second FFRT	3 1
TABLE IV PURGE TIME	Enter TIME in Seconds, 0 - 999 * For No-Purge Sequence selection "N", enter 000 ** For Modulation Sequence "M", the time is applied to both the high and low cycles, effectively doubling the specified time.	_ _ _
TABLE V IGNITION TRIAL 1st Safety Time	Enter TIME in seconds, 1 - 15	_ _
TABLE VI PILOT TIME 2nd Safety Time	Enter INTERRUPTED TIME in seconds, 0 - 99 To specify INTERMITTENT pilot, enter 00	_ _
TABLE VII POST-PURGE	Enter TIME in seconds, 0 – 99 For no post-purge, enter 00	_ _
TABLE VIII RECYCLE	Non- Recycle Recycle	N _ _ R _ _
AIR SWITCH	Standard, alarm if switch not made in 10s Sequence hold until switch makes	_ F _ _ P _
RESET	Standard automatic reset on power up Manual push button to start on power up	_ _ A _ _ M

Graham McKay, Manager, Certification Services
Advantica Technologies Ltd, Ashby Road, Loughborough, Leicestershire LE11 3GR

ADVANTICA